


Danfoss

**Instructions
RTD-CB
Back Flow Restrictor**

013R9467

013R9467




**013L1925 (DN 15)
013L1926 (DN 20)**

Danfoss

**Instructions
RTD-CB
Back Flow Restrictor**


013R9467

013R9467




**013L1925 (DN 15)
013L1926 (DN 20)**

1.




2.



3.

NB!



4.

DN	"A"	"B"
15	30	27
20	37	32

