

# Instructions Accessories

<b>1</b>		R 1/8	<b>003H6852</b>		<b>SW 12 (14 Nm)</b>	<b>SW 10</b>
		R 3/8	<b>003H6853</b>		<b>SW 12 (14 Nm)</b>	<b>SW 17</b>
		R 1/2	<b>003H6854</b>		<b>SW 12 (14 Nm)</b>	<b>SW 22</b>
		-	<b>003H6860</b>		<b>SW 12 (14 Nm)</b>	<b>SW 12 (14 Nm)</b>
<b>2</b>		G 1/8	<b>003H6931</b>		<b>SW 12 (14 Nm)</b>	<b>SW 14</b>
			<b>003H6932</b>			
<b>3</b>		R 1/8	<b>003H6857</b>		<b>SW 12 (14 Nm)</b>	<b>SW 10</b>
		R 3/8	<b>003H6858</b>		<b>SW 12 (14 Nm)</b>	<b>SW 17</b>
		R 1/2	<b>003H6859</b>		<b>SW 12 (14 Nm)</b>	<b>SW 22</b>



