



Operating Guide / Инструкция


APT DN 15-50











Installation / Монтаж

















5-8 Nm

8 mm


H min.	Int. thread / Внутр. резьба ISO 7/1	Ext. thread / Наруж. резьба ISO 228/1
80	Rp ⅓	G¾ A
80	Rp ¾	G1 A
100	Rp 1	G1¼ A
150	Rp 11/4	G1½ A
150	Rp 1½	G1¾ A
150	Rp 2	G2 ¼ A
	80 80 100 150	Rp ½ Rp ½ Rp ½ Rp ½ Rp ½ Rp 1 Rp 1½ Rp




© Danfoss | 2017.08 VI.A9.G1.00 | 1




Shut off / Отключение



Setting / Настройка



Flushing / Промывка



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.